

Slimline Network Freestanding Digital Poster – Wi-Fi (NON-ANDROID)


Hardware User Manual



Manual Version LW1.1h (NON-ANDROID)

 network player	 landscape or portrait	 scrolling text	 image, video & music	 super slim profile	 wide viewing angle
 24/7 usage	 HD high definition	 HDMI	 scheduling software	 eco-friendly power timer	 commercial grade screen

Our Full Product Range



Safety Instructions



- Please keep the display away from any heat sources. Place the display in a stable and well-ventilated place.
- Please handle with care as product contains glass.
- The holes or openings on the display are designed for ventilation. Do not cover or block the ventilation holes or openings with any objects.
- Remove protective covering from the screen before you use the display.
- Shut off the power supply before cleaning. Use a soft lint-free cloth instead of a tissue to wipe the screen.
- You may use a glass cleaner to clean the product as required. However, never spray the cleaner directly onto the display surface.
- Do not attempt to repair this product yourself! Improper disassembly of the product may invalidate the warranty and lead to possible danger
- If you have a problem that cannot be solved using the "Troubleshooting" guidelines, please contact your supplier.

Contents:

1.	Introduction	5
1.1	Box Contents	5
1.2	Product Overview	5
1.3	Remote Control	6
1.4	Replacing the Remote Control Battery	7
1.5	System Menu Operation	8
1.5.1	System Settings	9
1.5.2	Network Setting	12
1.5.3	Date & Time	17
1.5.4	On/Off Timer	18
1.5.5	Screen Mode	20
1.5.6	File Management	21
1.5.7	Exit.....	21
1.6	Display Settings	22
2.	System Operation	25
2.1	Supported Media Files	25
2.2	Inputs	25
3.	F.A.Qs and Troubleshooting Guide	26
3.1	Why is my screen displaying "Error (Screen Mode Unmatch)"?.....	26
3.2	How do I update my screen if it is not connected to the internet? (Plug and play method)	27
3.3	How do I play PowerPoint presentations on my display?.....	31
3.4	Video Format Conversion	32
3.4.1	Format Factory (Standard Definition)	32
3.4.2	HD Video Converter Deluxe (High Definition)	38
3.5	My media file does not fit properly on the screen	39
3.6	My moving GIF files will not move.....	39

Table of Figures

Figure 1 Product Overview.....	5
Figure 2 Home Screen.....	8
Figure 3 Screen Inputs.....	25

1. Introduction

Congratulations on your purchase of our product. Please read carefully and follow all instructions in the manual before first use.

The product should not be exposed to liquids dripping or splashing and no objects filled with liquids, such as vases, should be placed on the product.

For user convenience, a number of operations can be performed through the remote control.

Attention:

1. Do not change any default setting when it is unnecessary.
2. Keep the product far away from water during installation and use.

1.1 Box Contents

- 1 x Slimline Freestanding Digital Poster.
- 1 x Remote Control (with 2xAAA batteries).
- 1 x Key.
- 1 x Wi-Fi Aerial.

1.2 Product Overview




Figure 1 Product Overview


1.3 Remote Control



Button	Function
POWER/⏻	Power on or off
MENU	Display settings
SETUP	Menu settings
SOURCE/📺	Input source
▲	Up (navigation)
◀	Left (navigation)
▶	Right (navigation)
▼	Down (navigation)
▶/	Play media
■	Stop media
⏮	Previous
⏭	Next
🔊	Display settings
🔊+	Raise volume
🔊-	Lower volume

1.4 Replacing the Remote Control Battery

1. Slide the battery cover off, as shown below.
2. Remove the used batteries.
4. Insert the two new AAA batteries with their terminals corresponding to the indicators.
5. Put the cover back on.



1.5 System Menu Operation

In order to access the Setup Menu you must first press “STOP” button to go back to the home screen (pictured below). You can then bring up the Main Menu by pressing “SETUP”.



Figure 2 Home Screen

Main Menu includes following sub-menus: System Settings, Network Setting, Date & Time, ON/OFF Timer, Screen Mode, File Management and Exit.

Press ↑ & ↓ to select the right item, press “PLAY” to confirm selection. Choose Exit to exit the Main Menu.



1.5.1 System Settings

The sub-menus within this section are OSD Language, Clock Display, Scrolling Text, USB Port as well as Restore to Factory Settings and Return to Main Menu options.

OSD Language

The On Screen Display supports four languages – Chinese, English, French and Japanese. As with all menu operation press ↑ & ↓ to select the right item, press “PLAY” to confirm selection.




Clock Display

There are 5 options as pictured below:

- Top Left: The time will be displayed on top left of the screen.
- Bottom Left: The time will be displayed on bottom left of the screen.
- Top Right: The time will be displayed on top right of the screen.
- Bottom Right: The time will be displayed on bottom right of the screen.
- Off: The screen doesn't display time.

Note: You should set this to “Off” if you wish to add a clock via the Content Management System later.



Scrolling Text


This setting is irrelevant and is only significant if the screen is being used as a standalone display and is not networked.

USB Port

This setting is irrelevant and is only significant if the screen is being used as a standalone display and is not networked.

Restore To Factory Settings

Highlight “Yes” and press “PLAY” to restore factory settings; this will restore all system settings back to default.



Play Log and Synchronous Set

Please do not alter these settings, doing so may affect the functionality of your screen.

1.5.2 Network Setting

All settings within this section will be pre-set before you receive your goods. **Please do not change any of these settings unless you have adequate technical support.**

Server Setting

There are two options here, IP Mode and Domain Mode. This feature directs your screen to the server it will be collection information from. By default your screen should already be set to “IP Mode” with the IP address of: 193.35.59.74.80.

Local ID

This is your screen’s serial number. This is pre-set and cannot be changed.

MAC Address

This is your screen’s MAC Address. This is pre-set and cannot be changed.

IP Address

There are two options here, DHCP and Stable IP. By default your screen should already be set to DHCP mode however if your internet connection is subject to strict security settings or a firewall that only allows devices with authorised IP addresses to access the internet, you may need to input these settings into the “Stable IP” section. Here you will be asked to input the following:


- IP Address
- Subnet Mask
- Default Gateway
- DNS Server

Network Type

There are three options here, 3G, WiFi and LAN. Please make sure your screen is set to “WiFi”.

Wireless Network Settings


Here is where you set up your screen’s Wi-Fi connection. When you open this menu you should first see a list of available Wi-Fi networks, navigate to yours and press “PLAY”.




You will now be asked to enter your Wi-Fi network password. Press “PLAY” to bring up the on-screen keyboard.



If your password contains numbers you can access the number keypad by highlighting “123” and pressing “PLAY”. Once you have entered your password highlight the “Enter” key and press “PLAY”.




Now highlight “Connect” and press “PLAY”.




You will now see the following as your screen attempts to connect to your Wi-Fi network. The status should be “Connecting...”.



Once your screen has established a connection to your network the status will change to “Has connected”.



Finally, navigate to “Exit” and press “PLAY”. This will bring you back to the “Network Settings” menu. Navigate to “Save and Reboot” and press “PLAY”. This will save your network settings and ensure that every time your screen is powered up it will use these settings to connect to your Wi-Fi network.



Your screen is now ready to be updated via the CMS software.


Note: If you have made any changes to this section you must highlight and select “Save and Reboot” before they can take effect.

1.5.3 Date & Time

To set the date and time first select this menu to open the options pictured below. Next, use ← & → to select which value you wish to modify. Now you can change the setting by pressing ↑ & ↓.


We recommend that you keep the “Time Zone” set as “GMT”, the “NTP Mode Set” to “Sync at power on” and the “Daylight Saving Time” set to “ON”. This means that you do not have to manually set the time or date, it will automatically retrieve these details from the internet and update automatically at the beginning and end of summer.

To confirm, highlight “Update Date & Time” and pres “PLAY”. The date and time have been updated; you can now select Return to the Main Menu.



1.5.4 On/Off Timer


There are 2 modes to choose from - Daily and Weekly.



Weekly

You can set the on/off timer for each individual day of the week. For example, on Sunday, 6:00am on, 11:00am off:

1. Choose Weekly in the On/Off Timer menu, press "PLAY" to confirm:




2. Choose Timer in the Timer Mode, then the three Timer items become selectable. Choose the Status of Timer(1) to be ON, then make the On Time to be 06:00, Off Time to be 11:00.
3. Choose Save New Settings to finish the setting. Then highlight and select Return.

Daily

You can also set the on/off timer to be the same every day.

Choose Daily in the On/Off Timer menu, press “PLAY” to confirm:




There are 3 options available:

- Timer: user can set 3 timer groups; each group can set “On” or “Off”.
- Always On: after connecting the power cable, the product will powered on.
- Always Off: after connecting the power cable, the product will power off automatically one minute later.

Note: Any timer settings can later be overridden by the Content Management System. If you want all of your screens to have the same On/Off times we recommend that you control this using the Content Management Software to save time.


1.5.5 Screen Mode

You can change the orientation of the Home Screen and On Screen Display. Your screen should automatically be set to display in portrait, if it is not please select Vertical then highlight and select Save and Reboot. Your screen will now restart and when it reboots back to the Home Screen your OSD should be in the correct orientation.



1.5.6 File Management

Here, you can check storage information such as memory capacity, used space and free space. You can also format the disk. If your screen is connected to the internet when you do this the internal memory will be cleared and then content will be re-sent from the Content Management System. If you wish to clear the contents of your screen completely please disconnect from the internet and format disk.



1.5.7 Exit


Highlighting and selecting this section will exit the main menu.

1.6 Display Settings

As well as having a main system menu that can be accessed through your home screen, the unit also has a display setting menu for changing which input source is being displays as well as altering values such as brightness, contrast and saturation. This can be accessed at any time by pressing the “MENU” button on your remote control.

Source

Here you can select which video signal the screen displays. As a default it is set to “Digital Signage”, this means it will display anything set from your Content Management System. If you wish to connect your screen to a PC or external media player you can also select HDMI and VGA, to do so navigate to your desired input source and press the “PLAY” button on your remote control. To go back to the previous menu navigate to Return and press “PLAY” on your remote control.



System Setting

Here you can set the OSD Language to either English or Chinese. To go back to the previous menu navigate to Return and press “PLAY” on your remote control.



Picture

Note: These settings can also be altered remotely from the Content Management System and will override any settings you assign physically.

Here you can alter the overall image settings of your screen. The default value for all the image settings is 50. To adjust the Brightness, Contrast and Saturation of your display navigate to the setting, press "PLAY" on your remote and use the left and right navigation buttons to adjust the value accordingly. You can also alter the colour balance of your screen by highlighting ColourTemp, selecting User and then adjusting Red, Green and Blue balance in the same manner as before. The default value of these settings is 128.

Note: it is recommended not to change the image settings of your screen unnecessarily.



Exit

To exit from this Display Settings menu, navigate to Exit and press “PLAY”. If inactive for more than 10 seconds, you will automatically exit this menu.



2. System Operation

2.1 Supported Media Files

Media Type	Supported File Type
Image	JPG, BMP, PNG, GIF
Video	MPG, AVI, MP4, TS
Audio	MP3, WMA

1. This unit does NOT support WMV or FLV video file types.
2. This unit does NOT support Sony ATRAC3, DTS or Dobby HD audio file types.

NOTE: Video and image files should be a maximum 1080x1920 resolution (9:16 aspect ratio).

2.2 Inputs

Reset Button – Restarts power to unit, for convenient rebooting


LAN – Local Area Network Port

HDMI – High Definition Multimedia Interface Signal Input (for HD Video & Audio signal)

VGA – Video Graphics Array Signal Input (for Video signal)

3.5mm Audio Input

USB – Universal Serial Bus (for updating firmware)



***Extended to rear of unit**

Figure 3 Screen Inputs


3. F.A.Qs and Troubleshooting Guide

3.1 Why is my screen displaying "Error (Screen Mode Unmatch)"?

If you have published a playlist and your screen is now displaying "Playlist: Error (Screen Mode Unmatch)" it is because you have sent a Playlist that uses a Horizontal Template.

This can be easily solved by ensuring that the Template you use is a portrait or "Vertical" template and that your Freestanding Digital Poster's "Screen Mode" is set to "Vertical". If your Screen's menus and OSD are not correctly oriented please take the following steps

1. If your screen is playing content begin by pressing "Stop" on your remote control, this should take you back to the "Home" screen. Now press "Setup" on your remote and navigate down to "Screen Mode" and press "Play" on your remote. From here you can select Vertical. Do so by using the left or right button on your remote then highlight "Save and Reboot" and press "Play" on your remote.




2. Your screen will now restart and when the "Home" screen loads, should be in the correct orientation.
3. Now you must ensure that the template you use for this screen correlates with the orientation of the screen. As your Freestanding Digital Poster's "Screen Mode" is set to Vertical you should use a Vertical template.


3.2 How do I update my screen if it is not connected to the internet? (Plug and play method)

If your screen is not connected to the internet for whatever reason and you still want to update it you can do so by a physical plug and play method.


Begin by taking the normal steps to create a playlist and publish as normal. Then hover over the “Player” section of the Top Menu then click on “Player”. You will see a list of all of your screens.




Right-click on the screen you have sent the playlist to and select “Program Package”.




The “Program Package” window will then appear, click the “Pack Program” button.




The “Program Package Type” window will then appear. Tick the “Select All” checkbox to send all timer, download, display and current weather data to the screen as well. Then click “OK”.



After a few minutes an icon will appear in the “Download” column, when it appears, click it.



Once the download is complete your web browser will inform you and normally help direct you to your files. If you are using Google Chrome, select the option “Show in folder”.




Inside the zipped folder that has been downloaded should be two folders; “MEDIA” and “SYSTEM”. Copy these two folders onto a blank USB stick, and then plug it into the USB port of your screen. Allow the data to transfer to your screen and follow the on-screen prompts before removing the USB stick.

NOTE: If the zipped folder may require a password, this should be “123456”.

3.3 How do I play PowerPoint presentations on my display?

You can save the PowerPoint presentation as a JPEG File Interchange Format (JPEG). Microsoft PowerPoint software allows the user to do this. Once you have done this, you can upload your JPEG images and send them to the screen using the CMS.

1. Create or open a PowerPoint presentation.
2. Click “File” > “Save As”
3. Enter a File name
4. Click on “Save as type” scroll down and find the file extension “JPEG file interchange format”, as shown in the image below.



5. Click “Save”.
6. A message will appear asking if you would like to save all slides as JPEG’s
7. Once you have selected “Yes”, The JPEG images will be saved and are ready to use.

**NOTE: For the best resolution, you can use the following PowerPoint Page Setup:
Width 24cm; Height 42.6cm (9:16 Ratio).**

3.4 Video Format Conversion

If you have video files in a format that is not supported you will need to convert them (please see section 2.1.6 for Supported Media Files). There are two possible tools for converting video and are as follows.

3.4.1 Format Factory (Standard Definition)

This is a free multipurpose convertor that can be used for normal definition video files.


1. Download a free video convertor for Windows called Format Factory which can be found here:

<https://format-factory.en.softonic.com/>


2. Once you have finished downloading Format Factory, launch the software.




3. Next, access the “Video” section of the Top Menu then click on “All to MP4”.




4. Now click “Add File”




5. Next, locate and select the video files you wish to convert and click “Open”.




6. Now click “Output Setting”.




7. Set your “Video Settings” to the following values, then click “OK”:



8. Click “OK”.




9. Click “Start”.




10. Your video will now be converted. You can track it’s progress with the “Convert State” bar.



11. Now click “Output Folder” to access your converted video(s).



12. You will now be redirected to your converted videos. Please copy them to a location more convenient for uploading later.



3.4.2 HD Video Converter Deluxe (High Definition)

This is only really useful for High Definition videos.

Download link: <http://www.winxdvd.com/hd-video-converter-deluxe/>

This software is not free.

MP4 gives the best display quality. Please follow the following steps:

1. Select “**HD Video**” tab then the “**to HD MP4**” tab.
2. Change audio quality to 448 kbps, and change video quality to 12000, output image setting to custom size with custom aspect ratio, and video resolution to HD1080P(1920:1080), video codec to MPEG4.

See the screen shot below for the recommend settings.



3.5 My media file does not fit properly on the screen

This has happened because the file does not have a 9:16 aspect ratio (1080x1920). Please resize file to 1080x1920 pixels and try uploading the media onto the display once again.

3.6 My moving GIF files will not move.

As the screen recognises any .gif file as an image it will display the first frame of a moving gif for the allocated image display time.